

SQP  
LONDON E14

QUICK START  
GUIDE

# WELCOME TO YOUR NEW HOME

Welcome to your new home at  
South Quay Plaza.

This Quick Start Guide provides you with the essential information you will need when you first move into your apartment, and guidance on how to start using some of the features of your new home.

# C O N T E N T S

6

Contact Information

11

Utility Suppliers

8

Building Logistics

14

TV, Telephone  
& Internet Access

10

Systems In Your Home

15

Defects & Emergencies

17

Appliances



# CONTACT INFORMATION

## CONCIERGE

At South Quay Plaza you have a dedicated Concierge & Estate Management team who will be available 24 hours a day, 7 days a week, setting a new benchmark in service to residents.

Please ensure you complete the Residents Registration Form to benefit from these services. The registration form can be completed via the MySQP portal or provided by the Concierge.

Tel: 0204 509 1386  
Email: [Concierge@mysqp.co.uk](mailto:Concierge@mysqp.co.uk)

## ESTATE MANAGEMENT TEAM

Your Estate Management Agent is POD.

POD will work in collaboration with LGAH and Berkeley Homes and will manage South Quay Plaza on a day to day basis, providing you with a dedicated onsite team.

If you encounter any communal or wider estate issues, please direct these to POD, via the Concierge.

## MANAGEMENT PROVIDER

Legal & General Affordable Homes have appointed RHP as your Management Provider.

RHP will oversee any issues that fall outside of the Concierge Team's remit including defect reporting and service charge collections. RHP will liaise with POD and Berkeley Homes to offer the most suitable and timely response to your issue.

Tel: 0800 049 5409  
Email: [LGAH@rhp.org.uk](mailto:LGAH@rhp.org.uk)  
Web: [www.rhp.org.uk](http://www.rhp.org.uk)



# BUILDING LOGISTICS

## RESIDENTS ACCESS

As a resident you will be issued, by L&G, with 3 access control fobs. This will provide you with restricted access into the building via the revolving door and the adjacent disabled entry door.

Where additional fobs to the initial 3 are required, please contact RHP.

In the event your fob stops working, the Concierge team will be able to re-programme on site.

Legal & General residents fobs are restricted to floors 2 to 14.\*

\*Access to cycle storage facilities will be available.

Access will always be controlled or monitored by the Concierge. In the event of an emergency the doors release remotely, however, the Concierge will have full access to lock/unlock the main doors, where necessary.

The lobby will be staffed 24 hours a day by a member of the Concierge team, who will be there to greet, relay messages, and advise residents and their guests as they pass through into the lift lobby.

## LIFTS

The main core of the building is served by 6 lifts arranged into 4 passenger lifts and 2 goods lifts. All six lifts will respond to calls in unison. There is a call panel located on either side of the lift lobby.

To access the private lift lobby, you will need to present your fob to the reader located on the wall to release the motorised hinged door.

## CCTV

The exterior of the building, the entrance hall and the lift lobby is monitored by CCTV which is relayed to the Concierge desk and to the central security hub.

## GUEST ACCESS

Guests can either be provided entry by the Concierge, or call your apartment directly using the external Video Intercom, located adjacent to the revolving door.

When residents allow access to visitors, the Concierge is notified that a visitor has been permitted into the building and which resident they are there to visit.

## POST & DELIVERIES

Royal Mail deliveries will be posted directly to your front door.

It is important that you are aware all deliveries, especially vehicle-based deliveries, and courier deliveries, will enter the development via the basement loading bays.

Note that you will be automatically notified via e-mail once your parcel is available for collection. The average time until collection may of course vary during busier periods.

Parcels will not be readily available for collection once delivered by the courier therefore, any courier notification you receive will not mean your parcel is ready for collection.

Unfortunately, takeaways and food shopping deliveries cannot be accepted by the Concierge team as there are no facilities within which food can be suitably stored. Therefore, any food delivery courier will be directed to your apartment so that you can receive the delivery accordingly.

## CYCLE STORAGE

The secure cycle store\* area on level B2 requires use of a fob on entry and exit to release the lock on the secure cycle store gate.

Only authorised users will have access to this basement. Cyclists will use their fob to gain entry via the designated cycle entry door and to control the cycle lift that provides entry to the Level B2 cycle store area. Egress from the cycle store gate is via the request to exit button next to the gate.

Once at the ground floor, the resident simply needs to exit the cycle lift and apply the fob to the proximity reader to allow final exit onto the street.

Residents who wish to use the cycle storage facilities must complete a cycle registration form which can be found on the MySQP portal or provided by the Concierge.

\* Please note that during initial occupations a temporary bike store may be in operation.

## REFUSE DISPOSAL

A refuse chute is available for your use in the core lobby in every floor. Please separate waste into each separate type.

Using the Hopper Door:

- Make sure the Red Light is off – this means the chute is ready to use
- If the red light is on this means the chute is either in use or has been locked
- Locking of the chute would be to replace bins or clean etc.
- To dispose of bagged waste, begin with opening the hopper by the handle with one hand
- With your other free hand place waste bag in hopper
- Make sure your free hand is now out the way of the closing door
- Close/Release hopper by using the handle

- Please make sure your refuse has left the hopper once shut
- If the bag is still in the hopper you may need to reduce the amount you are putting in

Using the Bi-Separator:

Select the type of waste to be deposited down the chute by selecting the respective button on the panel above the door. The options are General Waste and Recycling.

Once selected the deflector on the bi-separator adjusts to the designated position.

When the bi-separator is in position the green led will illuminate.

At this point you can open the door using the handle with one hand and dispose of the waste with the other.

If the chute is busy, the red led will illuminate.

## LANDSCAPE AREAS

The communal gardens and outside spaces are accessible to the public and residents, subject to Estate regulations.

Please note that landscaped areas of the development are subject to a phased opening.

# SYSTEMS IN YOUR HOME

## UNDERFLOOR HEATING

A centralised boiler system provides heating and hot water to your apartment through the heat interface unit (HIU) situated in the utility cupboard.

An Underfloor heating system has been installed to each apartment bedroom, living room and bathroom. Room temperature can be adjusted using thermostat located in each room.

Located in the utility cupboard there is an interlock switch, this toggles between off (middle), down (cooling) and up (heating).

Please note, that adding rugs or floor coverings may reduce the effectiveness of the underfloor heating.

## MECHANICAL VENTILATION HEAT RECOVERY (MVHR)

A mechanical ventilation heat recovery (MVHR) unit has been installed in your apartment to provide continuous background ventilation.

This ensures continuous air changes throughout your apartment to help control humidity and air quality.

Your MVHR units are commissioned specifically for your apartment and settings should not be altered. It is also recommended that the unit is not turned off for long periods of time.

Boost mode will be enabled automatically when moisture is detected in the return air. There is a boost switch located on the integral control panel, this will increase the extract rate to the higher setting.


## VIDEO DOOR ENTRY

A Bticino 344502 video door entry panel has been installed in your apartment.

The building has two video entry visitor panels. One is on the external entrance door to the Concierge lobby and the other is on the inner lobby door to the lift lobby. Both of these panels have the ability to call the video entry handset in your apartment.

You will be able to view and speak to your visitor on the screen and enable access by following the prompts on the screen.

Contact to the Concierge will also be available through the door entry panel.



1. Bell adjustment and exclusion (Led)
2. Volume (Loudspeaker)
3. Brightness control
4. Colour setting and signalling LED
5. Door lock activation and/or door status red LED
6. Operating status two-colour red/green LED
7. Loudspeaker
8. Display
9. Microphone

# UTILITY SUPPLIERS

## ELECTRICITY

Your apartment's electricity supply is individually metered; therefore, you will be billed directly by the mains utility supplier which is currently Eon.

## HOT WATER AND HEAT

Your heating and hot water use is measured using a Guru Hub, a smart energy meter managed by Insite Energy. This ensures you are only charged for what you actually use along with a daily standing charge.

The Guru Hub is a popular metering and billing solution, which is linked to Insite's "PayPoint" payment system. Your Guru Hub allows you to easily monitor your heat & hot water use, as well as the payments you make.

## COLD WATER

Your cold-water consumption is individually metered and will be billed direct by the water supplier Thames Water.

Thames Water  
Tel: 0800 316 9800  
Web: [www.thameswater.co.uk](http://www.thameswater.co.uk)

## HEAT & COOLING BILLING – GURU SYSTEM

A Guru Hub smart energy meter has been installed within your apartment. The meter will measure your heating, hot water, and cooling usage.

Insite has installed a smart valve in your home which links your payments to your access to heating, hot water, and cooling. As long as your account is in credit, the valve will remain open and you will have access to heating, hot water, and cooling. If your account runs out of credit, the valve will close. Once you make a top-up payment, it will open again.

Please refer to the GURU User Guide for further information.



# TV, TELEPHONE & INTERNET ACCESS

## TV

Your apartment has been pre-wired to accept the following reception systems which are available at the wall socket locations in the living room and bedrooms:

- Freeview & Freeview HD
- FM & DAB Radio
- Sky Digital. Sky or Sky+, including Sky+HD & Sky 3D services
- Freesat & Freesat+

A TV, satellite receiver or other set top box may be plugged into any of the wall outlets using standard TV or satellite cables.

Virgin TV services are also installed at media points if you wish to use this option.

## TELEPHONE AND DATA

Within each apartment there are telephone & data outlets for direct connection of telephones or equipment. These are located in the living room and bedrooms.

All of the data outlet cables are connected in the utility cupboard to a main cabinet where all points are terminated ready for a hard wire connection if required.

All secondary telephone points are also taken back to the utility cupboard and terminated at the main cabinet; the Master telephone outlet installed by other can also be found located in the utility cupboard.

It is the resident's responsibility to arrange for connection of the primary point and BT line.

## INTERNET

For data/internet connectivity, please contact an internet service provider of your choice to carry out set-up and installation.

Master telephone and hard wire data connections are located in the utility cupboard for internet connection.

# DEFECTS & EMERGENCIES

## REPORTING DEFECTS

If you find any defects within your apartment, please report the defect to RHP's Customer Service Team using the details below.

Tel: 0800 049 5409  
Email: LGAH@rhp.org.uk.

Please ensure you provide the following so your defect can be recorded properly:

- Apartment number
- Photographs if possible
- Up-to-date contact details
- Issue Location
- Issue description
- Any other helpful information

RHP will validate whether the issue meets the definition of a defect, prior to reporting it to Berkeley Homes.

## RESPONSE TIMES FOR DEFECTS

Once you have contacted RHP, the response times by Berkeley are as follows:

- Initial response within 24 hours of receipt
- Appointment within 24 hours for an emergency — full power outage, loss of heating/ hot water, leak
- Appointment within 3 days for serious issues — i.e. external door locking issue
- Appointment within 7 days for all other issues — i.e. toilet flush running, cupboard not closing etc.
- A visit by a Berkeley Customer Service manager may be arranged to validate any of the above

## INSURANCE

We strongly advise that you arrange a comprehensive contents insurance policy covering you for fire, burglary, housebreaking, storm, flood, and other risks as soon as you move in.

Legal & General does not insure you for the contents of your home, or your personal possessions so cannot be held responsible should anything happen to these.

## DEFINITION OF A DEFECT

A defect is a fault in the construction of a new build property that adversely alters the practical use or enjoyment of the property, or a fault in the installation or manufacture of items of equipment which form part of the construction.

Common defects that may occur are:

- Leaks from pipes
- Heating or hot water problems
- Non-flushing toilets — this does not include blockages which would be the resident's responsibility
- Doors not closing properly
- Faults with extractor fans
- Light and electrical fittings (except bulbs that have exceeded their lifecycle) Replacement bulbs are the responsibility of the resident
- Shrinkage — where the resulting cracking is greater than 5mm in width or depth. Cracking of small width and depth are the responsibility of the resident and can be easily repaired during personalised decoration after purchase




# APPLIANCES

Appliances are gifted items, therefore it is advised that you register your appliances for services as part of the warranty.

# BUILT-IN OVEN BOSCH - HHF133BS0B

## CONTROL PANEL



- Buttons and display — The buttons are touch keys with sensors underneath. Simply touch a symbol to select the function. The display shows symbols for active functions and the time-setting options
- Function selector — Use the function selector to set the heating function or other functions. You can turn the function selector clockwise or anti-clockwise from the “Off” position
- Temperature selector — Use the temperature selector to set the temperature for the heating function or select the setting for other functions. You can only turn the temperature selector clockwise from the “Off” position, until it offers resistance. Do not turn the selector beyond this point

## TYPES OF HEATING & FUNCTIONS

Symbol	Function	Use
	3D hot air	For baking and roasting on one or more levels.
	Gentle hot air	For gently cooking selected types of food on one level without preheating.
	Grill, large area	For grilling flat items, such as steaks or sausages, for making toast, and for browning food.
	Circulated air grilling	For roasting poultry, whole fish and larger pieces of meat.

## INITIAL USE

The time will appear on the display once the appliance is connected to the power supply. Set the current time.

## SETTING THE TIME

Make sure that the function selector is set to the “Off” position.  
The time starts at “12:00”.

- Use the **-** or **+** button to set the time
- Touch the **⏸** button to confirm. The current time will be shown on the display

## SETTING THE HEATING FUNCTION AND TEMPERATURE

It is very easy to apply the settings you require to your appliance using the function and temperature selector.

Example in the picture: 3D hot air at 190°C.

- Use the function selector to set the heating function



- Use the temperature selector to set the temperature or grill setting



The appliance will start heating after a few seconds. Once the food is cooked, turn the function selector to the “Off” position to switch the appliance off


## SETTING THE COOKING TIME

You can set the cooking time for your food on the appliance.


Example below : Cooking time of 45 minutes. Details in the diagram may differ from what you see on your appliance.

- Set the type of heating and temperature or setting

- Touch the **⏸** button twice. The cooking time **45:00** will be highlighted on the display



- Use the **-** or **+** button to set the cooking time



## CLEANING ENAMEL SURFACES

Clean the smooth enamel surfaces with a dish cloth and hot soapy water or a vinegar solution. Then dry them with a soft cloth.

Soften baked-on food remnants with a damp cloth and soapy water. Use stainless steel wire wool or oven cleaner to remove stubborn dirt.

## CLEANING SELF-CLEANING SURFACES

If the self-cleaning surfaces no longer clean themselves sufficiently and dark stains appear, they can be cleaned using targeted heating.

Remove the rails, pull-out shelves, accessories, and ovenware from the cooking compartment beforehand. Thoroughly clean the smooth enamel surfaces in the cooking compartment, the inside of the appliance door and the glass cover on the interior lighting.

- Set the 3D hot air type of heating
- Set the maximum temperature
- Start the mode and leave it to run for at least one hour

The ceramic coating is regenerated.

# DISHWASHER BOSCH - SMV/ SPV

## BEFORE USING FOR THE FIRST TIME

Configure the settings for initial start-up.

## PERFORMING INITIAL START-UP


On initial start-up or after a reset to the factory settings, you will need to make settings.

1. Add special salt
2. Add rinse aid
3. Switch on the appliance.
4. Set the water softening system
5. Set the amount of rinse aid to be dispensed


## WATER SOFTENING SYSTEM

Hard water leaves limescale on the tub and tableware and parts of the appliance may become blocked. To ensure good dishwashing results, you can treat the water with special salt and the water softening system. To avoid damage to the appliance, water with a hardness above 9 °E must be softened.

## APPLIANCE INTERIOR



## CONTROL PANEL



1. On/off switch
2. Additional functions\*
3. Programme sequence display
4. Water supply display
5. Start button Start and reset button Rest 3 sec
6. Special salt refill indicator
7. Rinse aid refill indicator
8. Setting buttons
9. Programmes
10. Timer programming\*

\* depending on the features of your dishwasher

1. Rating plate
2. Detergent dispenser
3. Bottom basket
4. Dispenser for special salt
5. Lower spray arm
6. Tablet collecting tray
7. Top basket
8. Cutlery drawer\*
9. Emotion Light\*
10. Etagere
11. Upper spray arm
12. Filter system
13. Cutlery basket\*
14. Dispenser for rinse aid


\* depending on the features of your dishwasher

## CHILDPROOF LOCK

The childproof lock lets you protect children from possible hazards resulting from the appliance. Depending on the features of the model, the appliance comes with a door lock.


## ACTIVATING THE DOOR LOCK

1. Open the appliance door
2. Pull the catch of the childproof lock forwards ① and close the appliance door ②.



## DEACTIVATING THE DOOR LOCK

1. Open the appliance door
2. Push the catch of the childproof lock to the right ① and slide it backwards ②.



3. Close the appliance door


## RINSE AID SYSTEM

You can use the rinse aid system and rinse aid to get tableware and glasses rinsed perfectly without marks.

## ADDING RINSE AID

For optimum drying results, use rinse aid. Only use rinse aid for domestic dishwashers. If the rinse aid refill indicator lights up, top up with rinse aid. Only use rinse aid for domestic dishwashers.

1. Press the catch on the lid of the dispenser for rinse aid ① and lift ②



2. Add rinse aid up to the max mark



3. If rinse aid spills out, remove it from the tub

## CLEANING FILTERS

The filter system removes coarse soiling from the dishwashing cycle. Soiling in the dishwashing water may block the filters.

1. After each wash check the filters for residue
2. Turn the coarse filter anticlockwise and remove the filter system — check that no foreign objects fall into the sump
3. Pull down the micro filter to remove.
4. Press the locking catches together and lift the coarse filter out
5. Clean the filter elements under running water. Carefully clean the rim of dirt between the coarse and the fine filter
6. Re-assemble the filter system. Make sure that the locking catches on the coarse filter click into position
7. Insert the filter system into the appliance and turn the coarse filter clockwise. Make sure that the arrow markings match up

# CERAMIC HOB

## BOSCH - PKE611CA1E

### HOTPLATE AND RESIDUAL HEAT INDICATORS

The hotplate and residual heat indicators light up when a hotplate is warm:

- Hotplate indicator — during operation, shortly after you have switched on a hotplate
- Residual heat indicator — after cooking, when the hotplate is still warm

You can use the residual heat to save energy, e.g. to keep a small dish warm or to melt chocolate.

The hotplates

Hotplate	Activating & Deactivating
Single-circuit hotplate	
Dual-circuit hotplate	Switching on: turn the hotplate switch clockwise. Set the heat setting. Switching off: turn the hotplate switch to 0 and make new setting.

### SWITCHING THE HOB ON AND OFF

You can switch the hob on and off with the hotplate controls.

### SETTING A HOTPLATE

Adjust the heat setting of the hotplates using the hotplate controls.

Heat setting 1 = lowest setting  
Heat setting 9 = highest setting

The symbol in the display panel indicates the hotplate to which the display relates

Note: Hotplate temperature is regulated by the heat switching on and off. The heat may also switch on and off at the highest setting.

### CLEANING AND CARE

The information in this section provides help on how best to care for your hob. Suitable maintenance and cleaning products can be purchased from the after-sales service or on the Bosch online shop.

### CERAMIC

Clean the hob after each use. This will prevent spills from burning onto the ceramic. Only clean the hob when it has cooled down sufficiently. Use only cleaning agents which are suitable for glass ceramic.

Follow the cleaning instructions on the packaging.

Never use:


- Undiluted washing-up liquid
- Detergent intended for dishwashers
- Scouring agents
- Harsh cleaning agents such as oven spray or stain remover
- Abrasive sponges
- High-pressure cleaners
- Ground-in dirt can be best removed with a glass scraper, available from retailers

Using special sponges to clean glass ceramic achieves great cleaning results.

### HOB SURROUND

Please clean with only hot soapy water and a lint free cloth. Please dry thoroughly after cleaning.

### THE CONTROL PANEL



The hotplate controls are permanently fixed. They must not be removed. Forcibly removing the hotplate controls leads to them being destroyed.

### RISK OF FIRE

Hot oil and fat can ignite very quickly. Never leave hot fat or oil unattended. Never use water to put out burning oil or fat. Switch off the hotplate. Extinguish flames carefully using a lid, blanket, or something similar. The hotplate become very hot. Never place combustible items on the hob. Never place objects on the hob.

The appliance gets hot. Do not keep combustible objects or aerosol cans in drawers directly underneath the hob

### RISK OF BURNS

The hotplates and surrounding area (particularly the hob surround, if fitted) become very hot. Never touch the hot surface. Keep children at a safe distance.

### RISK OF INJURY

Saucepans may suddenly jump due to liquid between the pan base and the hotplate. Always keep the hotplate and saucepan bases dry.

### CAUSES OF DAMAGE

Damage	Cause	Action
Stains	Food spills	Remove spills immediately with a glass scraper
	Unsuitable cleaning agents	Only use cleaning agents which are suitable for ceramic
Scratches	Salt, sugar, and sand	Do not use the hob as a work surface or storage space
	Rough pot and pan bases scratch the ceramic	Check your cookware
Discolouration	Unsuitable cleaning agents	Lift the pots and pans when moving them
Blisters	Sugar, food with a high sugar content	Remove spills immediately with a glass scraper

# FRIDGE / FREEZER BOSCH - KIV38X22GB

## USING THE APPLIANCE

- Open the appliance door only briefly
- Transport purchased food in a cool bag and place quickly in the appliance
- Allow warm food and drinks to cool down before placing in the appliance
- Thaw frozen food in the refrigerator compartment in order to utilise the low temperature of the frozen food
- Always leave a space between the food and the rear panel
- Vacuum the back of the appliance once a year
- Pack food airtight
- Please note that the air on the rear panel of the appliance does not warm up so intensely. The appliance consumes less power if the warm air can escape

## SWITCHING ON THE APPLIANCE

1. Switch on the appliance with the main On/Off switch
2. The temperature display flashes until the appliance reaches the set temperature

### Operating tips:

- After the appliance has been switched on, it may take several hours until the set temperatures have been reached. Do not put in any food until the selected temperature has been reached
- The sides of the housing are partly heated slightly. This prevents condensation in the area of the door seal
- If the freezer compartment door cannot be immediately re-opened after it has been closed, wait until the resulting low pressure has equalised

## SWITCHING OFF THE APPLIANCE

Press the main On/Off switch (red circle becomes visible).

## DISCONNECTING THE APPLIANCE

If you do not use the appliance for a prolonged period:

1. Switch off the appliance
2. Pull out the mains plug or switch off the fuse
3. Clean the appliance
4. Leave the appliance open

## SETTING THE TEMPERATURE

Recommended refrigerator compartment temperature +4°C. Keep pressing the button °C until the display indicates the required temperature.

## FREEZER COMPARTMENT

The temperature in the refrigerator compartment will affect the temperature in the freezer compartment. Change the temperature in the refrigerator compartment in order to change the temperature in the freezer compartment. Temperatures which are set higher in the refrigerator compartment will increase temperatures in the freezer compartment.


Sticker OK (not all models). You can use sticker OK to check whether the temperature in the refrigerator compartment reaches +4 °C or lower.

If the sticker does not indicate OK, gradually reduce temperature. When the appliance is switched on, it may take up to 12 hours until the set temperature is reached.

### Ice cube tray:


1. Fill the ice cube tray 3/4 full with water and place in the freezer compartment
2. To loosen the ice cubes, twist the ice cube tray slightly or hold briefly under water

## GETTING TO KNOW YOUR APPLIANCE



- A. Refrigerator compartment
- B. Freezer compartment
- 1-4. Controls
- 5. Light switch
- 6. Glass shelves
- 7. Vegetable container
- 8. Frozen food container
- 9. Door shelf
- 10. Shelf for large bottles

## CONTROLS



1. Main On/Off switch Serves to switch the whole appliance on and off
2. Super display - this is lit when the super function is switched on
3. Temperature display refrigerator compartment in °C
4. Refrigerator compartment temperature selection button

## CLEANING AND CARE

- Do not use abrasive, chloride or acidic cleaning agents or solvents
- Do not use scouring or abrasive sponges
- Never clean the shelves or containers in the dishwasher
- Switch off the appliance before carrying out any cleaning
- Take out the food & store in a cool location
- If present: wait until the layer of frost in the refrigerator compartment has thawed
- Clean the appliance with a soft cloth, lukewarm water & a little pH-neutral washing-up liquid
- Wipe door seal with clear water and dry thoroughly with a cloth
- Reconnect and switch on appliance and put in food


## LIGHTING

Your appliance features a maintenance-free LED light.

Only customer service or authorised technicians may repair the light.


# WASHER / DRYER NEFF - V7446X2GB

## CONTROL PANEL



1. Select a programme. Can be rotated in either direction. To switch off the washer dryer, set the programme selector to Off
2. Select buttons °C Temp. (Temperature), rpm (Spin speed), Finished in and Dry for changing default settings. Select buttons SpeedPerfect/ EcoPerfect and Aqua Plus
3. Display panel for information
4. Start programme. Select the Start/Reload button to start, interrupt (e.g. reload laundry) and cancel the programme

## DISPLAY PANEL



1. Temperature for washing programme
2. Programme information
3. Programme progress symbols
4. Programme information and additional function symbols
5. Selectable drying mode and dry time

## SWITCHING ON THE APPLIANCE

1. Select the required programme with the programme selector. Can be rotated in either direction. The washer dryer is switched on



The following figures are indicated continuously on the display panel for the selected programme:

- The programme duration,
- The pre-set temperature,
- The maximum load (if the door is open)

## ADJUSTING THE WASHING PROGRAMME

You can use the displayed default settings or adjust the selected programme optimally to the laundry items by changing the default settings or selecting additional functions.

Options can be selected, deselected, or changed depending on the progress of the programme.

The buttons are sensitive, they only need to be touched gently. If the button °C Temp, rpm, Finished in is held down, the setting options are automatically scrolled through

Touch the °C Temp button to set desired washing temperature.

Touch the SpeedPerfect/ EcoPerfect button until the indicator light comes on.

## ADJUSTING THE DRYING PROGRAMME

Touch the Dry button to set the desired drying mode or drying time (only for an individual drying programme).


## DOSING

Dose the detergents and care products according to:

- Water hardness (ask your water supply company)
- The manufacturer's specifications on the packaging
- The amount of laundry
- Soiling

## FILLING THE DISPENSERS

- Pull out the detergent drawer
- Pour in detergent and/or cleaning product



Dispenser **I** — Detergent for pre-wash  
 Dispenser — Softener, starch. Do not exceed the maximum load  
 Dispenser **II** — Detergent for main wash, water softener, bleach, stain remover  
 Dispenser **A\*** — For dosing liquid detergent

## CHILDPROOF LOCK


Activating/deactivating: Touch and hold the buttons rpm and Finished in for approx. 3 seconds. The symbol is indicated in the display. If the button signal is activated, an acoustic signal sounds.

- lights up: The childproof lock is activated
- flashes: The childproof lock is active and the programme selector has been adjusted. To prevent the symbol from flashing, reset the programme selector to the initial programme. The symbol lights up again

## CLEANING THE DETERGENT DISPENSER

If it contains detergent or fabric softener residue:

1. Pull out the detergent drawer. Depress the insert and remove the drawer completely
2. Take out insert: using your finger, press insert upwards



3. Clean the detergent dispenser and insert with water and a brush and dry
4. Attach the insert and lock into position (push the cylinder onto the guide pin)
5. Insert detergent drawer

# EXTRACTOR HOOD ELICA - SKLOCK-LED-60

## OPERATION

The hood is fitted with a control panel with aspiration speed selection and a light switch to control cooking area lights.


## MAINTENANCE

Clean using only a cloth dampened with neutral liquid detergent. Do not clean with tools or instruments. Do not use abrasive products. Do not use alcohol.

## GREASE FILTER

The grease filter must be cleaned once a month using non aggressive detergents, either by hand or in the dishwasher, which must be set to a low temperature and a short cycle.

When washed in a dishwasher, the grease filter may discolour slightly, but this does not affect its filtering capacity.




## CHARCOAL FILTER

The saturation of the charcoal filter occurs after more or less prolonged use, depending on the type of cooking and the regularity of cleaning of the grease filter.

In any case it is necessary to replace the cartridge at least every four months.

The charcoal filter may NOT be washed or regenerated.



## REPLACING LAMPS

The hood is equipped with a lighting system based on LED technology.

The LEDs guarantee an optimum lighting, a duration up to 10 times as long as the traditional lamps and allow to save 90% electrical energy.

To replace lights, contact authorised spare part centre.

